ASSEMBLY GUIDELINE FOR WFH - WOODWING CHAIR



Zip Zap Zoom							
PART LIST				1. PRESS FIT THE FRONT SUPPORT AND REAR SUPPORT INTO THE CROSS MEMBERS AS SHOWN	2. FASTEN THE LH AND RH ARM TO THE ASSEMBLY FROM STEP 1 USING 2Nos OF A BOLT AND 2 Nos OF NUT EACH.		O Nos OF ALLEN BOLT M6 x 60
1		FRONT SUPPORT	1 pc	BELOW. (THE LONGER SUPPORT REMAINS AT THE FRONT)	MOTE:- ALWAYS NUT(6) SUCH TI LINE IS IN HORIZ	AAT THE \\\\\\\\\	
2		CROSS MEMBER	2 pcs	3_	DIRECTION (ARR	ows 🕅 10	
3		REAR SUPPORT	1 pc	PUSH 2	NUTS		7
4		LH ARM	1 pc	CROSS MEMBER REAR	8	6	
5		RH ARM	1 pc	FRONT PUSH	5 7		ВОТТОМ VIEW
6	10	NUT	4 pc	4. FIX THE BACKREST WITH 4 Nos O	OF ALLEN BOLT 9	5. FINAL ASSEMBLED PROD	UCT
7		ALLEN BOLT M6x60mm	6 pcs			A	
8		ALLEN KEY	1 pc				
9		BACKREST	1 pcs				
10		SEAT	1 pcs		8		
11	0	ALLEN BOLT M6x40mm	4 pc				~

- Note: 1. For chairs, use clean dry cloth to wipe fabric wrapped seats, nylon base and metal power coated surfaces
 - 2. Vacuum cleaning is recommended once in 3 months for chairs

